

LogTag TRED30 Data Logger Battery Replacement Instructions

The LogTag TRED30 Data Logger battery life is typically one year of operation. Each LogTag comes with a replacement battery; check original box before purchasing a new battery. The end of battery life is indicated by a low battery symbol in the upper right corner of the logger display. Within 30 days of the first appearance of this symbol, the battery should be replaced. Since VFC providers must download temperature reports every two weeks, it is acceptable to replace a low battery the next time temperature data is downloaded. To replace the battery:

1. Download the LogTag to save recorded data.
2. The LogTag TRED30 has a replaceable CR2032 battery. Battery access sits behind the square white label (under the calibration sticker) on the back of the recorder's case.
3. Peel the calibration sticker up from the bottom left corner to reveal a small notch. Pry up the white square. A small flathead screwdriver works well.
4. Using a coin, twist the battery cover a quarter of a turn counter clockwise to remove.
5. Remove the battery.
6. Insert the right edge of the replacement CR2032 battery into the compartment.
7. Firmly press on the left side of the battery to click the battery into place.
8. Replace the battery cover, turning it clockwise to lock into place.
9. Replace the calibration sticker.
10. Dock the LogTag in the docking station to clear the low battery symbol.